



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	BMW	MOD.	X5	YEAR	01 →	PETROL	<input type="checkbox"/>	DIESEL	<input checked="" type="checkbox"/>
ALARM/SIREN POSITION									
CENTRAL POSITION									
POWER SUPPLY									
IGNITION WIRE									
DIRECTION INDICATORS									
ELECTRIC WINDOWS									
CENTRAL DOORS LOCKING									
IMMOBILISATION POINT									
STARTER									
BONNET SWITCH									
DOORS AND BOOT SWITCHES									



CAR SECURITY


SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N°147

Diagram for direction indicators connection for **BMW X5**



Note: This information is not binding, therefore it must be considered only an example for installation purposes that must be executed as per the instructions given on the product installation manual.