

CAR SECURITY

www.cobra.it

MAKE FORD MOD. FOCUS YEAR. 02 2nd sem. → PETROL X

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the wheel house, passenger's side.

CENTRAL UNIT POSITION

Position the modular systems and the modules behind the glove compartment, passenger's

POWER SUPPLY

+ 30: connect to the 6 mm² RED wire located in a multiway connector in the fuse box.

- 31: connect to one of the original ground terminals.

IGNITION WIRE

+ 15/54: connect to the GREY/ORANGE wire located in the wiring harness coming out of the ignition key.

DIRECTION INDICATORS

Connect to the BLUE wire, at the position nr. 3 (or as alternative nr.12) and to the BLUE wire, at the position nr. 4 (or as alternative nr.13) located in the light blue connector, on the coming out of the central locking unit, behind the passenger's side glove compartment.

ELECTRIC WINDOWS

Positive controls at rest

Front window, driver's side:

Cut the wires: YELLOW, at the position nr. 9, in the 16 way white connector, directly on the coming out of the windows push botton panel and WHITE located at the position nr. 5, in the 7 way green connector, on the coming out of the relay of the automatism inside the driver's side door.

Front window, passenger's side:

Cut the YELLOW/VIOLET and WHITE/VIOLET wires located in the wiring harness coming out of the wiring harness of the connector of the driver's side door.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the BLACK/ORANGE wire, at the position nr. 19, in the dark grey connector (lock) and to the BLACK/GREEN wire, at the position nr. 16, in the green connector (unlock). The connectors are located on the central locking unit, behind the passenger's side glove compartment.

IMMOBILISATION POINT

Gasoil pump

Cut the GREEN/BLACK wire, at the position nr. 3, in the 8 way white connector, fitted on the fuses box.

STARTER

+50: Cut the 2,5 mm² GREY wire located in a multiway connector, in the fuse box.

BONNET SWITCH

Install an additional switch on the headlamp support plate, driver's side.

Perimetric connection with separated lines

Connect to the BLACK/YELLOW wire in the white connector for the driver's side front door, to the BLACK/BLUE wire in the white connector for the passenger's side front door, to the BLACK/ORANGE wire in the green connector for the driver's side rear door and to the BLACK/GREEN wire in the grey connector for the passenger's side rear door.

The connectors are located on the central locking unit, behind the passenger's side glove compartment.

Note: it is suggested to separate the lines with diodes.

Perimetric connection directly to the ceiling lamp control

As alternative: connect to the BLACK/BLUE wire, at the position nr. 3, in the dark grey connector. The connectors are located on the central locking unit placed behind the passenger's side glove compartment.

BOOT SWITCH

Connect to the BLACK/YELLOW wire, in the brown connector coming out of the central locking unit located behind the passenger's side glove compartment.

Note: This information is not binding, therefore it must be considered only an example for installation purposes that must be executed as per the instructions given on the product installation manual.

fofoc02gbd2s.doc

REV. 00