



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

[www.cobra.it](http://www.cobra.it)

MAKE	OPEL	MOD.	ZAFIRA	YEAR	99 →	PETROL	<input checked="" type="checkbox"/>	DIESEL	<input type="checkbox"/>
<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens in the engine compartment, behind the driver's side headlamp.								
<b>CENTRAL UNIT POSITION</b>	Position the modular systems and the modules under the left side of the dashboard, driver's side.								
<b>POWER SUPPLY</b>	<b>+ 30:</b> connect to the general supply wiring that drives the fuse box. <b>- 31:</b> connect with a ring terminal directly to the car body.								
<b>IGNITION WIRE</b>	<b>+ 15/54:</b> connect to the 0,75 mm <sup>2</sup> BLACK wire at the position nr. 77 of the 80 way green connector behind the bulkhead, driver's side.								
<b>DIRECTION INDICATORS</b>	Connect to the 0,75 mm <sup>2</sup> BLACK/WHITE wire at the position nr. 65 and to the BLACK/GREEN wire at the position nr. 19 located in the 80 way green connector behind the bulkhead, driver's side.								
<b>ELECTRIC WINDOWS</b>	<b>Comfort closing</b> The closing of the windows is obtained timing the RED/BLUE doors closure wire to 24s.								
<b>CENTRAL DOORS LOCKING</b>	<b>Negative control signal</b> Connect to the 0,75 mm <sup>2</sup> RED/WHITE wire (unlock) and RED/BLUE wire (lock) located in the wiring harness coming out of the driver's side door.								
<b>IMMOBILISATION POINT</b>	<b>Fuel pump</b> Cut the 1,5 mm <sup>2</sup> RED/BLUE wire at the position nr.1 in the 80 way green connector behind the driver's side bulkhead.								
<b>STARTER</b>	<b>+50:</b> Cut the 2,5 mm <sup>2</sup> BLACK/RED wire located in the wiring harness coming out of the connector of the control board key.								
<b>BONNET SWITCH</b>	Install an additional switch on the headlamp support plate of the driver's side headlamp.								
<b>DOORS SWITCH</b>	Connect to the 0,5 mm <sup>2</sup> GREY wire at the position nr. 29 in the 80 way green connector located behind the driver's side bulkhead.								
<b>BOOT SWITCH</b>	Connect to the 0,75 mm <sup>2</sup> BROWN/WHITE wire located in the wiring harness coming out of the boots interior lamp.								