



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **PEUGEOT** MOD. **106** YEAR **98** → PETROL  DIESEL

<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens in the engine compartment on the shock absorber support, driver's side. Pass the cables through the original rubber sleeve located on the left of the servobrake.
<b>POWER SUPPLY</b>	<b>+ 30:</b> connect to the 4 mm <sup>2</sup> RED/WHITE wire located in the general power supply of the fuse box. <b>- 31:</b> connect with a cable terminal to the car body.
<b>IGNITION WIRE</b>	<b>+ 15/54:</b> connect to the 4 mm <sup>2</sup> ORANGE wire located in the wiring harness of the 2 way grey connector near the ignition key.
<b>DIRECTION INDICATORS</b>	Connect to the 1 mm <sup>2</sup> GREEN wire marked nr. 2343 and to the RED wire marked nr. 2333 located in the wiring harness that drives the facilities behind the left lateral sill cover, driver's side.
<b>ELECTRIC WINDOWS</b>	<b>Positive control signal</b> <b>Front window, driver's side:</b> cut the 1 mm <sup>2</sup> GREY wire marked 604. <b>Front window, passenger's side:</b> cut the 1 mm <sup>2</sup> GREY wire marked 608. Connections should be made directly in the wiring harnesses of the respective control switches located on the central consolle.
<b>CENTRAL DOORS LOCKING</b>	<b>Negative control signal</b> Connect to the 0,5 mm <sup>2</sup> GREY wire marked nr. 623 (unlock) and to the BROWN wire marked nr. 626 (lock) located in the wiring harness coming out of the driver's side door.
<b>IMMOBILISATION POINT</b>	<b>Fuel pump</b> Cut the 1,5 mm <sup>2</sup> WHITE wire marked nr.121 located in the wiring harness that drives the facilities behind the lateral sill cover, driver's side.
<b>IMMOBILISATION POINT</b>	<b>Relay control</b> Cut the 1,5 mm <sup>2</sup> GREY wire marked nr. 120 located in the wiring harness coming out of the 3 way black connector linked to the inertial switch in the engine compartment.
<b>STARTER</b>	<b>+ 50:</b> Cut the 4 mm <sup>2</sup> BLUE wire located in the wiring harness coming out of the 2 way black connector near the ignition key.
<b>BONNET SWITCH</b>	Install an additional switch on the front headlamp support plate, near the original bonnet bumper rubber, passenger's side.
<b>DOORS SWITCH</b>	Connect to the 0,75 mm <sup>2</sup> RED wire marked nr. 300 located in the wiring harness, behind the lateral support cover, driver's side.
<b>BOOT SWITCH</b>	Connect to the 0,5 mm <sup>2</sup> LIGHT BLUE wire marked nr. 319 located in the wiring harness of the 2 way connector of the boot lamp.