



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

PEUGEOT

MOD.

106

YEAR

98 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment on the shock absorber support, driver's side. Pass the cables through the original rubber sleeve located on the left of the servobrake.

POWER SUPPLY

+ 30: connect to the 4 mm² RED/WHITE wire located in the general power supply of the fuse box.
- 31: connect with a cable terminal to the car body.

IGNITION WIRE

+ 15/54: connect to the 4 mm² ORANGE wire located in the wiring harness of the 2 way grey connector near the ignition key.

DIRECTION INDICATORS

Connect to the 1 mm² GREEN wire marked nr. 2343 and to the RED wire marked nr. 2333 located in the wiring harness that drives the facilities behind the left lateral sill cover, driver's side.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the 1 mm² GREY wire marked 604.

Front window, passenger's side:

cut the 1 mm² GREY wire marked 608.

Connections should be made directly in the wiring harnesses of the respective control switches located on the central consolle.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the 0,5 mm² GREY wire marked nr. 623 (unlock) and to the BROWN wire marked nr. 626 (lock) located in the wiring harness coming out of the driver's side door.

IMMOBILISATION POINT

Gasoil pump

Cut the 1,5 mm² GREY wire marked nr. 120 located in the wiring harness coming out of the 3 way black connector linked to the inertial switch in the engine compartment.

STARTER

+50: Cut the 4 mm² BLUE wire located in the wiring harness coming out of the 2 way black connector near the ignition key.

BONNET SWITCH

Install an additional switch on the front headlamp support plate, near the original bonnet bumper rubber, passenger's side.

DOORS SWITCH

Connect to the 0,75 mm² RED wire marked nr. 300 located in the wiring harness, behind the lateral support cover, driver's side.

BOOT SWITCH

Connect to the 0,5 mm² LIGHT BLUE wire marked nr. 319 located in the wiring harness of the 2 way connector of the boot lamp.