



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **PEUGEOT** MOD. **307** YEAR **01** → PETROL DIESEL

ALARM/SIREN POSITION	Position the compact alarms and the sirens in the wheelhouse, driver's side, near the original horn.
CENTRAL UNIT POSITION	The modular systems and the modules should be positioned under the dashboard, driver's side.
POWER SUPPLY	+ 30: connect with a wire terminal to the clamp marked '+30' located in the feed rod, in the black box, on the side of the battery, in the engine compartment. - 31: connect with a wire terminal to the clamp marked 'GND' located in the feed rod, in the black box, on the side of the battery, in the engine compartment.
IGNITION WIRE	+ 15/54: connect to the 2,5 mm ² LIGHT BLUE wire located in the connector coming out of the ignition key.
DIRECTION INDICATORS	Connect to the wires at the positions nr. 13 and nr. 14 coming out of the wiring harness of the 16 way black connector.
ELECTRIC WINDOWS	Motors controls This information is not available at the moment.
CENTRAL DOORS LOCKING	Original door motor controls Cut the GREY wire, at the position nr. 15 (unlock) and the RED wire, at the position nr. 13 (lock) located in the wiring harness coming out of the 16 way grey connector. Refer to the diagram nr. 98 for serie Bridge antithefts and to the diagram nr. 98A for 3100 serie antithefts.
IMMOBILISATION POINT 1	Fuel pump Cut the LIGHT BROWN wire, marked nr.1235, located in the little wiring harness placed behind the sill cover, driver's side.
IMMOBILISATION POINT 2	Relay pump feeding Cut the LIGHT BROWN wire, marked nr.1235, located at the position nr. 11, coming out of the connector marked 'GRIS', in the driver's side fuse box, in the engine compartment.
STARTER	+ 50: Cut the YELLOW wire located in the wiring harness coming out of the 3 way connector, placed on the left of the steering column.
BONNET SWITCH	Install an additional switch on the front headlamp support plate, driver's side.
DOORS SWITCH	Connect to the wire, at the position nr. 32 of the green connector, located in the connexion with white covering, in the lower part of the fuse box, under the driver's side dashboard. Note: this is a positive polarity control.
BOOT SWITCH	If the vehicle is provided with the boot lamp, connect to the supply wire of the lamp.



CAR SECURITY


SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N° 98

Diagram to make the lock and unlock of the doors on
PEUGEOT 307 year 2001
(for Bridge serie antithefts)





CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N°98A

Diagram to make the lock and unlock of the doors on
PEUGEOT 307 year 2001
(for 3100 and 3900 series antithefts)

