

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

www.cobra.it

REV. 00

X PETROL PORSCHE CARRERA 4 03 MOD. YEAR MAKE DIESEL Position the compact alarms and the sirens on the driver's side wheelhouse. ALARM/SIREN POSITION Position the modular sistems and the modules under the central tunnel or under the **CENTRAL UNIT POSITION** passenger's side seat. POWER SUPPLY +30: connect directly to the positive pole of the battery. -31: connect with a cable terminal directly to the ground terminal located behind the driver's side sill cover. +15/54: connect to the 1,5 mm² BLACK wire located in the wiring harness on the side of the **IGNITION WIRE** fuse box coming out of the ignition key; as alternative directly in the connector coming out of the ignition key. Connect to the BLACK/WHITE and BLACK/GREEN wires located in the wiring harness coming DIRECTION INDICATORS out of the connector coming out of the operating central placed under the driver's side seat. **CENTRAL DOORS LOCKING** Positive control Connect to the WHITE/BLACK wire (lock) and to the WHITE/BLACK wire (unlock) located in the wiring harness coming out of the 5 way connector of the OPEN/CLOSE push-button located on the dashboard. **IMMOBILISATION POINT** Fuel pump Cut the 2 mm² RED/WHITE wire at the position nr.4, of the "C" line coming out of the relay pump connector. It is suggested to install an additional relay. **STARTER** +50: Cut the BLACK wire in the wiring harness coming out of the connector of the ignition key. **BONNET SWITCH** Connect to the BROWN/LIGHT BLUE wire in the wiring harness coming out of the boot lamp. **DOORS SWITCH** Connect to the YELLOW/BROWN wire in the wiring harness coming out of the driver's side door. **BOOT SWITCH** Connect to the GREY/BLACK wire at the position nr.1 in the 40 way light blue connector coming out of the central placed behind the left side covering, in the front boot. HORN CONTROL **Negative control** Connect to the WHITE/BROWN wire in the wiring harness coming out of the connector of the relay marked nr.53 located under the driver's side dashboard.

pocar03gbb.doc