



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

SEAT

MOD.

CORDOBA*

YEAR

98 →

PETROL

DIESEL

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, on the support of the shock absorber, driver's side.

CENTRAL UNIT POSITION

Position the modular systems and the modules on the left, under the dashboard, driver's side.

POWER SUPPLY

+ **30**: connect to the 4 mm² RED wire located in a 2 way connector in the fuse box.
- **31**: connect with a terminal directly to the car body.

IGNITION WIRE

+ **15/54**: connect to the 1mm² BLACK/YELLOW wire located in the shunting box of the fuse box under the dashboard, driver's side.

DIRECTION INDICATORS

Connect to the 1,5 mm² WHITE/BLACK and WHITE/VIOLET wires located in the 8 way black connector coming out of the original alarm central unit under the gloves compartment.

ELECTRIC WINDOWS

Mixed polarity

Front window, driver's side:

cut the 2 mm² WHITE/BLACK wire.

Front window, passenger's side:

cut the 2 mm² WHITE wire.

Rear window, driver's side:

cut the 2 mm² YELLOW/BLACK wire.

Rear window, passenger's side:

cut the 2 mm² YELLOW wire.

The connections are made directly in the wiring harness coming out of the respective windows switches.

CENTRAL DOORS LOCKING

Positive control signal

Connect to the RED/WHITE wires (unlock) and GREY/LIGHT BLUE (lock) located in the 12 way black connector coming out of the original alarm central unit under the gloves compartment.

IMMOBILISATION POINT

Fuel pump

Cut the RED/YELLOW wire located in the 6 way black connector marked "M" at the position nr.6 in the fuse box.

STARTER

+**50**: Cut the RED/BLACK wire located in the 10 way red connector marked "H" at the position nr.1 in the fuse box.

BONNET SWITCH

Install an additional switch on the headlamp support plate.

DOORS SWITCH

Connect to the 1 mm² GREEN/LIGHT BLUE wire located in the 12 way black connector coming out of the original alarm central unit under the gloves compartment.

BOOT SWITCH

Connect to the 1 mm² BROWN/WHITE wire located in the wiring harness coming out of the boot light.