



SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **TOYOTA** MOD. **COROLLA VERSO*** YEAR **03** → PETROL
DIESEL

* Models with original equipment keyless entry system.

- ALARM/SIREN POSITION** Position the compact alarms and the sirens on the passenger's side wheel house.
- CENTRAL UNIT POSITION** Position the modular systems and the modules under the dashboard, on the left of the steering column.
- POWER SUPPLY** **+30:** connect to the 6 mm² WHITE wire located in the 1 way white connector, in the central part of the fuse box.
-31: connect to a ground terminal located behind the driver's side left lateral bulkhead.
- IGNITION WIRE** **+15/54:** connect to the BLACK/ORANGE wire, at the pos. nr.10, in the 6 way black connector, in the fuse box.
- DIRECTION INDICATORS** Connect to the GREEN/YELLOW wire, at the position nr. 6, and to the GREEN/BLACK wire at the position nr. 11, in the 24 way white connector, in the fuse box.
- ELECTRIC WINDOWS**
Version with "Sol" equipment
 It is not possible to make the connection of the electric windows as the windows central units lose the programming.
Version with "Base" equipment
 To make the windows locking it is sufficient to disconnect the positive rising of each push-button located in the wiring harness coming out of the push-button panel, directly inside the driver's side door.
- ACTIVAT./DEACTIVATION CONTROLS**
Connections antitheft/vehicle
- | Art.3800 | Vehicle | Position |
|--------------|--------------|-----------------------------------|
| YELLOW/BLACK | RED | Pos. nr.8, 12 way blue connector |
| GREY/BLACK | BLUE | Pos. nr.9, 12 way blue connector |
| VIOLET | GREEN/YELLOW | Pos. nr.6, 24 way white connector |
| ORANGE | ground | car body |
| VIOLET/WHITE | ground | car body |
| ORANGE/WHITE | ground | car body |
- The 12 way blue connector is located behind the driver's side sill cover. The 24 way white connector is located directly in the fuse box. Refer to the **fitting diagram nr.191**.
- IMMOBILISATION POINT** **Fuel pump**
 Cut the BLACK/RED wire, at the position nr. 10, in the 24 way white connector, in the fuses box.
- STARTER** **+50:** cut the BLACK wire, at the pos. nr. 7, in the 10 way grey connector, behind the passenger's side glove compartment.
- BONNET SWITCH** Install an additional switch on the headlamp support plate, driver's side.
- DOORS AND BOOT SWITCH** Connect to the RED/YELLOW wire, at the position nr. 17, in the 24 way white connector, in the fuse box.

FITTING DIAGRAM NR.191

