



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

TOYOTA

MOD.

YARIS*

YEAR.

01 →

PETROL
DIESEL

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, on the support of the shock absorber, driver's side. Pass the cables through the original rubber sleeve located in the bulkhead that divides the engine compartment from the passenger's compartment, driver's side.

CENTRAL UNIT POSITION

Position the modular system and the modules under the dashboard, driver's side.

POWER SUPPLY

+ 30: connect to the 3 mm² RED/WHITE wire located in a multiway connector at the entrance of the fuse box.
- 31: connect with a terminal directly to the car body.

IGNITION WIRE

+ 15/54: connect to the 1,5 mm² BLUE wire located in the wiring harness of the 13 way white connector, behind the left lateral bulkhead, driver's side.

DIRECTION INDICATORS

Connect to the 1,5 mm² GREEN/BLACK wire with GREY references and to the GREEN/YELLOW wire with GREY references located in the bundle of cables behind the sill cover, driver's side.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the 1,5 mm² RED wire located in the 10 way white connector in the original push-button panel.

Front window, passenger's side:

cut the 1,5 mm² BLUE/RED wire located in the 13 way white connector behind the sill cover, driver's side.

ACTIVAT./DEACTIVATION CONTROLS

Connections antitheft/vehicle

Art.3800	Vehicle	Position
YELLOW/BLACK	GREEN/ORANGE	25 way white connector
GREY/BLACK	+30	Supply in the fuse box
VIOLET	+30	Supply in the fuse box
ORANGE	+30	Supply in the fuse box
VIOLET/WHITE	+30	Supply in the fuse box
ORANGE/WHITE	+30	Supply in the fuse box

The 25 way white connector is located on the central on the side of the instrument board. Refer to the **diagram nr. 86**.

IMMOBILISATION POINT

Fuel pump

Cut the 1 mm² BLACK/RED wire with GREY references located in the wiring harness behind the sill cover, driver's side.

STARTER

+50: Cut the 0,75 mm² BLACK wire with GREY references located in the wiring harness coming out of the connector of the ignition key.

BONNET SWITCH

Install an additional switch on the headlamp support plate, driver's side.

DOORS SWITCH

Connect to the 0,75 mm² RED/YELLOW wire with GREY references located in the 25 way white connector on the central doors locking unit (light blue color) located to the left of the instrument board.

BOOT SWITCH

Install an additional switch on the rear bulkhead.



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N°86

Diagram to make the connection of art. 3800 on
TOYOTA YARIS

