



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **VOLKSWAGEN** MOD. **BORA** YEAR **99** → PETROL DIESEL

ALARM/SIREN POSITION	Position the compact alarms and the sirens in the engine compartment, on the bulkhead that divides the engine compartment from the passenger's compartment. To pass the cables use the original rubber sleeve located under the bowl for the brakes liquid.
CENTRAL UNIT POSITION	Position the modular system and the modules under the driver's side dashboard or, alternatively, behind the left bulkhead, driver's side.
POWER SUPPLY	+ 30: connect with an eyelet terminal to the pin marked "+30" located on the terminal strip on the lower part of the fuse box. - 31: connect with an eyelet terminal on the grounding shunt up on the left of the superior part of the fuse box.
IGNITION WIRE	Connect to the 2 mm ² BLACK wire on the central part of the fuse box located on the left lateral bulkhead, driver's side.
DIRECTION INDICATORS	Connect to the 1 mm ² BLACK/WHITE wire and to the BLACK/GREEN wire located in the wiring harness coming out of the connector of the lights switch.
ELECTRIC WINDOWS	The closing of the windows is obtained timing the closure control signal (violet) of the alarm system to 24s.
CENTRAL DOORS LOCKING	Negative control signal Connect to the 0,75 mm ² YELLOW/BLUE wire (lock) and to the GREEN/RED wire (unlock) located in the wiring harness that goes from the push-button panel (on/off) to the switch inside the driver's side door.
IMMOBILISATION POINT 1	Cut the 1 mm ² BLUE/YELLOW wire in the wiring harness coming out of the 6 way light brown connector located on the connectorholder plate under the driver's side dashboard.
IMMOBILISATION POINT 2	Cut the 1 mm ² RED/VIOLET wire coming out of the fuse marked nr. 32 located in the fuse box on the left lateral bulkhead, driver's side.
BONNET SWITCH	Install an additional switch on the front headlamp support plate. As this plate is plastic made, it is necessary to make a ground connection of the switch body.
DOORS SWITCH	Connect to the 1 mm ² GREY/BLUE wire at the position nr. 16 of the connector coming out of the central doors locking unit located under the driver's side dashboard.
BOOT SWITCH	Connect to the 1 mm ² BROWN/BLACK wire located in the wiring harness of the sill cover, driver's side.