



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **VOLKSWAGEN** MOD. **BORA*** YEAR **99** → PETROL
DIESEL

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION	Position the compact alarms and the sirens on the right of the engine compartment or, alternatively, on the support bracket of the battery.
CENTRAL UNIT POSITION	Position the modular systems and the modules under the driver's side dashboard above the fuse box.
POWER SUPPLY	+ 30: connect to the clamp marked "+30" on the terminal strip located under the driver's side dashboard. Alternatively connect to the RED/GREEN wire coming out of the arrows switch. - 31: connect to a shunting of the general bulks located under the driver's side dashboard.
IGNITION WIRE	+ 15/54: connect to 1 mm ² BLACK/GREEN wire located at the position nr. 2 of the LIGHT BROWN connector, under the driver's side dashboard.
DIRECTION INDICATORS	Connect to the 1 mm ² WHITE/BLACK wire and to the 1 mm ² GREEN/BLACK wire located at the positions nr. 13 and nr. 14 of the 23 way black connector marked T23 of the power plant of the vehicle.
ELECTRIC WINDOWS	Comfort closing The closing of the windows is obtained with the serial radio control.
ALARM CONTROLS	Boots motor control signal Connect to the BLUE wire at the position T23/20 for the insertion and to the GREEN wire at the position T23/19 for the setting off, located in the connector coming out of the central doors locking unit marked J393.
IMMOBILISATION POINT 1	Gasoil pump Cut the BLACK/VIOLET wire at the position nr. 1 of the 6 way light brown connector marked "T6" located on the left of the driver's side dashboard.
IMMOBILISATION POINT 2	Starter Cut the RED/BLACK wire at the position nr. 3 of the 6 way light brown connector marked "T6", under the left side of the dashboard.
BONNET SWITCH	Install an additional switch on the front headlamp support plate. As this plate is plastic made, it is necessary to make a ground connection of the switch body.
DOORS SWITCH	Connect to the BLUE/GREY wire at the position nr. 16 of the 23 way black connector of the central doors locking unit.
BOOT SWITCH	Connect to the BROWN/BLACK wire at the position nr. 15 of the 23 way black connector of the central doors locking unit.