



## SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **VOLKSWAGEN** MOD. **NEW BEETLE\*** YEAR **02** → PETROL   
DIESEL

\* Models with original equipment keyless entry system.

**ALARM/SIREN POSITION** Position the compact alarms and the sirens behind the headlamp, passenger's side.

**CENTRAL UNIT POSITION** Position the modular systems and the modules under the dashboard.

**POWER SUPPLY** **+30:** connect to the RED wire located in the wiring harness coming out of the ignition key.  
**- 31:** connect to the ground terminal located behind the sill cover, driver's side.

**IGNITION WIRE** **+15/54:** connect to the YELLOW wire located in the wiring harness coming out of the ignition key.

**DIRECTION INDICATORS** Connect to the PINK wire at the position nr. A3 and to the VIOLET wire at the position A4, in the connector marked P202, in the lockings central, behind the steering column.

**ELECTRIC WINDOWS** **Negative control**  
**Comfort closing**  
The closing of the windows is obtained timing at 12/24s the YELLOW/BLUE wire located in the horizontal wiring harness inside the driver's side door.

**ACTIVAT./DEACTIVATION CONTROLS** Refer to the **fitting diagram nr. 157**.

**IMMOBILISATION POINT** **Gasoil pump**  
Cut the RED/VIOLET wire located in the wiring harness coming out of the fuse marked nr.32 placed in the fuse box, on the left, of the left lateral bulkhead.

**STARTER** **+50:** Cut the RED/BLACK wire located in the wiring harness coming out of the 6 way light brown connector, located on the connector's holder plate, under, on the left of the driver's side dashboard.

**BONNET SWITCH** Install an additional switch on the front headlamp support plate, driver's side.

**DOORS SWITCH** Connect to the GREEN/GREY wire, at the position 27, in the connector marked P201, in the central locking unit placed behind the steering column.

**BOOT SWITCH** Connect to the VIOLET wire, at the position nr. 23, in the connector marked P201, in the central locking unit placed behind the steering column.

**FITTING DIAGRAM NR.157**

Diagram to connect art. 3800 on  
**VOLKSWAGEN NEW BEETLE year 2002**

