



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	AUDI	MOD.	A3 *	YEAR.	02 ®	PETROL	<input checked="" type="checkbox"/>
						DIESEL	<input type="checkbox"/>

* Models with original equipment keyless entry system.

- ALARM/SIREN POSITION** Position the compact alarms and the sirens in the engine compartment, on the ABS bracket. Pass the cables through the rubber sleeve located on the panel that divides the engine compartment and the passenger's compartment near the shock absorber, driver's side.
- CENTRAL UNIT POSITION** Position the modular systems and the modules behind the fuse box, under the dashboard, driver's side.
- POWER SUPPLY** **+30:** connect to the 4 mm² RED wire located in the general supply wiring of the fuse box.
- 31: connect with a ground terminal on the left, under the dashboard, driver's side.
- IGNITION WIRE** **+15/54:** connect to the 2 mm² BLACK wire located in a multiway connector in the central part of the fuse box on the left of the dashboard.
- DIRECTION INDICATORS** Connect to the 1,5 mm² BLACK/WHITE and BLACK/GREEN wire located under the lateral left , driver's side.
- ELECTRIC WINDOWS** **Negative control signal**
The closing is obtained timing at 24s. the GREY wire, at the position nr. 1, in the light brown connector, behind the left lateral bulkhead, driver's side.
- ACTIVAT./DEACTIVATION CONTROLS** **Connections antitheft/vehicle**
- | Art. 3800 | Vehicle | Position |
|--------------|-------------|--|
| GREY/BLACK | GREEN/BLACK | Pos. nr.2, 11 way black connect., white insert |
| YELLOW/BLACK | ground | car body |
| VIOLET | ground | car body |
| ORANGE | ground | car body |
| VIOLET/WHITE | ground | car body |
| ORANGE/WHITE | ground | car body |
- Refer to the **diagram nr. 160.**
- IMMOBILISATION POINT** **Fuel pump**
Cut the 1,5 mm² BLUE/RED wire located in the wiring harness under the left sill cover, driver's side.
- STARTER** **+50:** Cut the 1,5 mm² BLACK/RED wire located in the wiring harness coming out of the connector of the ignition key.
- BONNET SWITCH** Install an additional switch on the headlamp support plate, driver's side.
- DOORS SWITCH** Connect to the BROWN/WHITE wire located in the wiring harness under the lateral left sill cover going to the rear.
- BOOT SWITCH** Connect to the 1 mm² WHITE/BLACK wire, at the position nr.4, of the 6 way black connector behind the door on the left of the boot.



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N°160

Diagram to connect art. 3800 on
AUDI A3 year 2002

