



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

[www.cobra.it](http://www.cobra.it)

MAKE

**OPEL**

MOD.

**ZAFIRA\***

YEAR

**99** →

PETROL   
DIESEL

\* Models with original equipment keyless entry system.

#### ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, behind the driver's side headlamp.

#### CENTRAL UNIT POSITION

Position the modular systems and the modules under the left side of the dashboard, driver's side.

#### POWER SUPPLY

+ **30**: connect to the general supply wiring that drives the fuse box.  
- **31**: connect with a ring terminal directly to the car body.

#### IGNITION WIRE

+ **15/54**: connect to the 0,75 mm<sup>2</sup> RED wire at the position nr. 4 of the 12 way black connector of the central doors locking unit behind the sill cover, passenger's side.

#### DIRECTION INDICATORS

Connect to the 0,75 mm<sup>2</sup> BLACK/WHITE wire at the position nr. 65 and to the BLACK/GREEN wire at the position nr. 19 located in the 80 way green connector behind the bulkhead, driver's side.

#### ELECTRIC WINDOWS

##### Comfort closing

It is made by the original radio control.

#### ALARM CONTROLS

##### Positive control signal

Connect to the 0,75 mm<sup>2</sup> BLUE/BLACK wire for the setting on located at the position nr. 10 in the 28 way black connector and to the 1,5 mm<sup>2</sup> RED/BLACK wire for the setting off located at the position nr. 8 in the 12 way black connector. The connectors are located on the coming out of the central doors locking unit behind the sill cover, passenger's side.

**Note: you can set on the alarm system by pressing for two consecutive times the closing key of the original radio control.**

#### IMMOBILISATION POINT

##### Fuel pump

Cut the 1,5 mm<sup>2</sup> RED/BLUE wire at the position nr. 1 in the 80 way green connector located behind the bulkhead, driver's side.

#### STARTER

+**50**: Cut the 2,5 mm<sup>2</sup> BLACK/RED wire located in the wiring harness coming out of the ignition key.

#### BONNET SWITCH

Install an additional switch on the headlamp support plate, above the driver's side headlamp.

#### DOORS SWITCH

Connect to the 0,5 mm<sup>2</sup> GREY wire at the position nr. 29 in the 80 way green connector located behind the driver's side bulkhead.

#### BOOT SWITCH

Connect to the 0,75 mm<sup>2</sup> BROWN/WHITE wire located in the wiring harness coming out of the boot lamp.