



## SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

**PEUGEOT**

MOD.

**EXPERT**

YEAR.

**03** →

PETROL   
DIESEL

**ALARM/SIREN POSITION**

Position the compact alarms and the sirens on the driver's side wheelhouse.

**CENTRAL UNIT POSITION**

The modular systems and the modules should be positioned under the dashboard, on the side of the steering column.

**POWER SUPPLY**

**+30:** connect to the RED wire located in the wiring harness coming out of the connector of the ignition key.  
**- 31:** connect to a ground terminal located under the driver's side dashboard.

**IGNITION WIRE**

**+15/54:** connect to the ORANGE wire located in the wiring harness coming out of the ignition key.

**DIRECTION INDICATORS**

Connect to the PINK/WHITE and BLUE/BLACK wires in the white connector coming out of the push button of the direction indicators.

**ELECTRIC WINDOWS**

**Positive control signal at rest**

**Front window, driver's side:**

cut the VIOLET/YELLOW and VIOLET/BLACK wires.

**Front window, passenger's side:**

cut the WHITE/RED and VIOLET/WHITE wires.

The above mentioned wires are located in the connector coming out of the central behind the passenger's side glove compartment on the coming out of the driver's side door.

**CENTRAL DOORS LOCKING**

**Negative control signal**

Connect to the WHITE/GREEN wire (lock) and to the LIGHT BLUE/VIOLET wire (unlock) located in the wiring harness coming out of the connector of the driver's side door.

**IMMOBILISATION POINT 1**

**Inertial switch**

Cut the wire located on the entrance of the inertial switch, near the battery, in the engine compartment.

**IMMOBILISATION POINT 2**

**Gasoil pump**

Cut the LIGHT BLUE/WHITE wire in the wiring harness coming out of the gasoil pump, in the engine compartment, above the driver's side wheelhouse.

**STARTER**

**+50:** Cut the RED/GREEN wire located in the wiring harness coming out of the ignition key.

**BONNET SWITCH**

Install an additional switch on the front headlamp support plate, driver's side.

**DOORS SWITCH**

Connect to the BLACK/VIOLET wire located in the wiring harness coming out of the connector of the push button of the driver's side front door.