



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

PORSCHE

MOD.

BOXSTER

YEAR

97 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the side of the battery, passenger's side. The modular system and the modules should be positioned under the dashboard, driver's side. Pass the cables through the original rubber core hitch, near the core hitch of the door, driver's side.

POWER SUPPLY

+ 30: connect to the wire located in the connector at the entrance of the fuse box.
- 31: connect with a cable terminal to one of the ground terminal located behind the left lateral panel, driver's side.

IGNITION WIRE

+ 15/54: connect to the BLACK/RED wire located in the wiring harness coming out of the fuse marked "B9", inside the fuse box.

DIRECTION INDICATORS

Connect to the 1 mm² BLACK/WHITE and BLACK/GREEN wires located in the wiring harness on the side of the fuse box, under the dashboard, driver's side.

ELECTRIC WINDOWS

Negative control signal

The closing of the windows is obtained timing the doors closing wire at 24s.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the BROW/RED wire (unlock) and BROWN/WHITE wire (lock) located in the wiring harness coming out of the driver's side door.

IMMOBILISATION POINT

Fuel pump

Cut the WHITE/GREEN wire located in the wiring harness coming out of the relay on the relay holder plate, under the dashboard, driver's side.

STARTER

+50: Cut the YELLOW wire coming out of the wiring harness of the ignition key.

BONNET SWITCH (engine compartment)

Connect to the 1 mm² YELLOW/BROWN wire located in the wiring harness coming out of the lamp of this compartment.

DOORS SWITCH

Connect to the BROWN/YELLOW wire located in the wiring harness near the internal fuse box.

BOOT SWITCH (luggages compartment)

Connect to the 1 mm² YELLOW/BROWN wire located in the wiring harness coming out of the lamp of this compartment.