



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

RENAULT

MOD.

CLIO 1.2 RT

YEAR.

00 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the support of the battery, in the engine compartment. Pass the cables using the original rubber of the bonnet opener cable.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the dashboard, driver's side.

POWER SUPPLY

+ **30**: connect to the 4 mm² WHITE wire located at the entrance of the fuse box.
- **31**: connect with a cable terminal directly to the car body.

IGNITION WIRE

+ **15/54**: connect to the YELLOW wire at the position nr. 5, in the connector marked "L", on the superior part of the central located under the dashboard, driver's side.

DIRECTION INDICATORS

Connect to the WHITE/BROWN wire at the position nr. 4 and to the ORANGE/BROWN wire at the position nr. 5 in the connector marked "M", on the superior part of the central placed under the dashboard, driver's side.

ELECTRIC WINDOWS

Mixed control signals

Front window, driver's side:

cut the VIOLET wire directly in the wiring harness coming out of the serial push botton, inside the driver's side door.

Front window, passenger's side:

cut the WHITE/ORANGE wire (positive control) and the WHITE/ORANGE wire (negative control) located in the wiring harness coming out of the driver's side door.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the GREY wire at the position nr. 22 (unlock) and to the PINK wire at the position nr. 7 (lock) located in the wiring harness coming out of the 26 way yellow connector placed on the relay holder central, under the dashboard, driver's side.

IMMOBILISATION POINT 1

Fuel pump

Cut the 1 mm² LIGHT BROWN wire located in the wiring harness coming out of the black connector, behind the right lateral bulkhead, passenger's side.

IMMOBILISATION POINT 2

Inertial switch

Cut the LIGHT BROWN wire located in the wiring harness coming out of the connector of the inertial switch placed on the support of the shock absorber, driver's side.

STARTER

+**50**: Cut the ORANGE wire located in the wiring harness coming out of the connector of the ignition key.

BONNET SWITCH

Install an additional switch on the front headlamp support plate.

DOORS SWITCH

Connect to the GREEN wire at the position nr. 13 in the connector of the central doors locking unit.

BOOT SWITCH

Connect to the GREY wire directly on the coming out of the boot lamp.