



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

[www.cobra.it](http://www.cobra.it)

MAKE

**RENAULT**

MOD.

**EXPRESS**

YEAR

**98** →

PETROL   
DIESEL

#### ALARM/SIREN POSITION

Position the compact alarms and the sirens in the windshield wiper compartment, driver's side. Position the modular systems and the modules under the dashboard, passenger's side. To route the cables use the original rubber sleeve located between the battery and the wing, passenger's side.

#### POWER SUPPLY

+ **30**: connect to the ground terminal at the entrance of the fuse box, under the dashboard, passenger's side.  
- **31**: connect with cable terminal to the car body.

#### IGNITION WIRE

+ **15/54**: connect to the 1 mm<sup>2</sup> YELLOW wire located in the wiring harness coming out of a multiway brown connector behind the fuse box.

#### DIRECTION INDICATORS

Connect to the WHITE wire at the position nr. 4 and to the GREY wire at the position nr. 6 of the 8 way black connector of the lights switch.

#### ELECTRIC WINDOWS

Not foreseen as original equipment.

#### CENTRAL DOORS LOCKING

##### Positive control signal

Connect to the PINK/GREY wire (unlock) and to the WHITE wire (lock), located in the wiring harness coming out of the connector of the white relay behind the fuse box, under the dashboard, passenger's side.

#### IMMOBILISATION POINT

##### Gasoil pump

Cut the 1,5 mm<sup>2</sup> YELLOW wire located in the wiring harness directly on the coming out of the gas oil pump, in the engine compartment.

#### STARTER

+ **50**: Cut the ORANGE wire located in the wiring harness coming out of the 2 way black connector, under the steering column.

#### BONNET SWITCH

Install an additional switch on the left lateral bonnet stop.

#### DOORS SWITCH

Connect to the 1 mm<sup>2</sup> LIGHT BROWN/GREY wire coming out of the door switch and located behind the right lateral panel, passenger's side.