



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **VOLKSWAGEN**

MOD.

GOLF 4

YEAR

98 →

PETROL

DIESEL

ALARM/SIREN POSITION

Position the modular system and the siren in the engine compartment, on the bulkhead between the engine compartment and the cabin. Run the cables through the available rubber plug located under the brake fluid reservoir.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the dashboard on the driver's side. Alternatively, behind the left-side bulkhead on the driver's side.

POWER SUPPLY

+ 30: connect with an eyelet terminal to the pin marked "+30" of the terminal strip located on the lower part of the fuse box.
- 31: connect with an eyelet terminal on the grounding shunt up on the left of the fuse box.

IGNITION WIRE

Connect to the 2 mm² BLACK wire in the central area of the fuse box located on the left-side bulkhead on the driver's side.

DIRECTION INDICATORS

Connect to the 1 mm² BLACK/WHITE and BLACK/GREEN wires in the wiring harness from the connector of the turn indicator switch.

ELECTRIC WINDOWS

For total window roll up time set the alarm unit roll-up pulse to 24s.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the 0,75 mm² YELLOW/BLUE lock wire and GREEN/RED unlock wire in the wiring harness that runs from the push-button panel to the switch inside the driver's door.

IMMOBILISATION POINT 1

Cut the 1 mm² BLUE/YELLOW wire in the wiring harness that comes out of the 6 way light brown connector located on the connector plate under the dashboard on the driver's side.

IMMOBILISATION POINT 2

Cut the 1 mm² RED/VIOLET wire that comes off the fuse marked nr. 32 at the fuse box above the left lateral bulkhead on the driver's side.

BONNET SWITCH

Install an additional switch on the headlamp support grill, up on the left of the headlamp on the driver's side.

DOORS SWITCH

Connect to the 1 mm² GREY/BLUE wire at position nr. 16 at the connector that comes out of the central lock unit located under the dashboard on the driver's side.

BOOT SWITCH

Connect to the 1mm² BROWN/BLACK wire in the wiring harness of the driver's floor trim.