

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE PORSCHE

MOD.

996

YEAR

03 →

PETROL DIESEL

X

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the driver's side wheelhouse.

CENTRAL UNIT POSITION

Position the modular sistems and the modules under the central tunnel or under the

passenger's side seat.

POWER SUPPLY +30: connect directly to the positive pole of the battery.

-31: connect with a cable terminal directly to the ground terminal located behind the driver's

side sill cover.

IGNITION WIRE +15/54: connect to the 1,5 mm² BLACK wire located in the wiring harness on the side of the

fuse box coming out of the ignition key; as alternative directly in the connector coming out of

the ignition key.

DIRECTION INDICATORS Connect to the BLACK/WHITE and BLACK/GREEN wires located in the wiring harness coming

out of the connector coming out of the operating central placed under the driver's side seat.

CENTRAL DOORS LOCKING Positive control

Connect to the WHITE/BLACK wire (lock) and to the WHITE/BLACK wire (unlock) located in

the wiring harness coming out of the 5 way connector of the OPEN/CLOSE push-button

located on the dashboard.

IMMOBILISATION POINT Fuel pump

Cut the 2 mm2 RED/WHITE wire at the position nr.4, of the "C" line coming out of the relay

pump connector. It is suggested to install an additional relay.

STARTER +50: Cut the BLACK wire in the wiring harness coming out of the connector of the ignition key.

BONNET SWITCH Connect to the BROWN/LIGHT BLUE wire in the wiring harness coming out of the boot lamp.

DOORS SWITCHConnect to the YELLOW/BROWN wire in the wiring harness coming out of the driver's side

door.

BOOT SWITCH Connect to the GREY/BLACK wire at the position nr.1 in the 40 way light blue connector

coming out of the central placed behind the left side covering, in the front boot.

HORN CONTROL Negative control

Connect to the WHITE/BROWN wire in the wiring harness coming out of the connector of the

relay marked nr.53 located under the driver's side dashboard.