



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

[www.cobra.it](http://www.cobra.it)

MAKE	VOLVO	MOD.	S 60	YEAR	02 →	PETROL	<input checked="" type="checkbox"/>	DIESEL	<input type="checkbox"/>
<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens on the wheel house, passenger's side. Pass the cables using the original core hitch located under the driver's side wheel house.								
<b>CENTRAL UNIT POSITION</b>	The modular systems and the modules should be positioned under the dashboard.								
<b>POWER SUPPLY</b>	<b>+30:</b> connect to the 4 mm <sup>2</sup> RED/WHITE wire located in the wiring harness coming out of the multiway connector at the entrance of the fuse box. <b>- 31:</b> connect to one of the cable terminals coming out of the original power supply behind the left lateral panel, driver's side.								
<b>IGNITION WIRE</b>	<b>+ 15/54:</b> connect to the BLUE/RED wire located in the wiring harness coming out of the connector fixed to the central placed, in vertical way, under the driver's side dashboard.								
<b>DIRECTION INDICATORS</b>	Connect to the GREEN wire, at the position marked 'SH1' and to the GREEN/WHITE wire, at the position marked 'SH2', behind the central placed, in vertical way, under the driver's side dashboard.								
<b>ELECTRIC WINDOWS</b>	<b>Positive control signal</b> <b>Front window, drivers side:</b> cut the VIOLET wire, at the position nr.4, in the grey connector coming out of the driver's side push buttons panel. <b>Front window, passengers side:</b> cut the VIOLET wire, at the position nr.4, in the grey connector coming out of the passenger's side push buttons panel. <b>Rear window, drivers side:</b> cut the GREEN/BROWN wire, at the position 'M11' of the central placed, in vertical way, under the dashboard, driver's side. <b>Rear window, passengers side:</b> cut the GREEN/BROWN wire, at the position 'M124' of the central placed, in vertical way, under the dashboard, driver's side.								
<b>CENTRAL DOORS LOCKING</b>	<b>Negative control signal</b> Connect to the VIOLET/WHITE wire at the position nr.13 (lock) and to the BLUE/WHITE wire at the position nr.12 (unlock) located in the 30 way green connector coming out of the windows push buttons panel directly inside the driver's side door.								
<b>IMMOBILISATION POINT</b>	<b>Fuel pump</b> Cut the LIGHT BLUE wire, at the position 'MI/12', behind the central placed, in vertical way, under the driver's side dashboard.								
<b>STARTER</b>	<b>+ 50:</b> cut the GREEN wire located in the wiring harness coming out of the ignition key.								
<b>BONNET SWITCH</b>	Install an additional switch on the front headlamp support plate, driver's side.								
<b>DOORS SWITCH</b>	Connect to the WHITE wire located in the wiring harness coming out of the lamp placed near the driver's side foot rest. <b>Note:</b> The lamp control is at positive polarity.								
<b>BOOT SWITCH</b>	Connect to the WHITE wire located in the wiring harness coming out of the lamp placed in the boot. <b>Note:</b> The lamp control is at positive polarity.								