



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

[www.cobra.it](http://www.cobra.it)

MAKE

**PEUGEOT**

MOD.

**RANCH**

YEAR

**98** →

PETROL   
DIESEL

**ALARM/SIREN POSITION**

Position the compact alarms and the sirens in the engine compartment, near the support of the shock absorber, driver's side.

**CENTRAL UNIT POSITION**

Position the modular systems and the modules under the left side of the dashboard, driver's side.

**POWER SUPPLY**

**+ 30:** connect to the general supply wiring that drives the fuse box.  
**- 31:** connect with a ring terminal directly to the car body.

**IGNITION WIRE**

**+ 15/54:** connect to the 2,5 mm<sup>2</sup> LIGHT BLUE wire located in the wiring harness coming out of the round connector under the fuse box.

**DIRECTION INDICATORS**

Connect to the GREEN wire marked nr. 2334 and to the GREEN wire marked nr. 2333 located in the wiring harness behind the sill cover, driver's side.

**ELECTRIC WINDOWS**

**Positive control signal**

**Front window, driver's side:**

cut the 2 mm<sup>2</sup> BLUE wire.

**Front window, passenger's side:**

cut the 2 mm<sup>2</sup> LIGHT BLUE wire.

The connections are made directly in the wiring harnesses of the respective control switches.

**CENTRAL DOORS LOCKING**

**Negative controls**

Connect to the GREEN wire marked nr. 6291 (unlock) and the GREEN wire marked nr. 6292 (lock) located in the wiring harness of the green connector, behind the left lateral bulkhead, driver's side.

**IMMOBILISATION POINT**

**Gasoil pump**

Cut the 1,5 mm<sup>2</sup> GREEN wire located in the wiring harness coming out of the electropumps inertial switch that is installed on the shock absorber, driver's side.

**STARTER**

**+50:** Cut the 1,5 mm<sup>2</sup> RED wire located in the wiring harness coming out of the 2 way connector of the ignition key.

**BONNET SWITCH**

Install an additional switch on the front headlamp support plate of the driver's side headlamp.

**DOORS SWITCH**

Connect to the GREEN wire marked nr. 305 located in the wiring harness coming out of the connector of the driver's side door.

**BOOT SWITCH**

Install an additional switch on the member of the rear doorstop.